

Ⓓ Aufbauanleitung

Ⓕ Notice de montage

Ⓖ Montagehandleiding

Ⓒ Montážní návod

Ⓗ Szerelési útmutató

Ⓙ Montaj talimatları

Ⓖ Assembly instruction

Ⓙ Istruzioni di montaggio







Ⓖ Instrukcja montażu

Ⓒ Navod na montaž

Ⓙ Instrucțiuni de montaj

Ⓙ Инструкция по монтажу

# 36-4526-82-000





# Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam • Nazwa • Jméno • Názov  
Név • Denumire • Isim • Название




Nr. • No. • N° • Č • Sz • Номер

Typ • Type • Tip • Tipus • Druh • Тип • Тип




## Detail specification

A. i. Nr.	Article Nr.	pcs
①	193102-32	x1
②	193104-32	x1
③	193103-32	x1
④	193101-32	x1
⑤	193201-32	x2
⑥	193202-32	x2
⑦	193302-32	x2
⑧	193301-32	x1
⑨	193410-82	x1




		mm	
a	1-000013-00	8x40	x14
b	1-000025-07	M6x90	x14
c	1-000095-07	10x13	x14
d	1-000188-07	4x60	x8
e	1-000179-00	50/75	x2
f	1-000178-00	50/75	x2
g	1-000174-07	4.5x15	x16
h	1-000015-07	Z4	x1


1-000001=




1.



2.



3.



4.

