

Ⓓ Aufbauanleitung

Ⓕ Notice de montage

Ⓖ Montagehandleiding

Ⓒ Montážní návod

Ⓗ Szerelési útmutató

Ⓓ Montaj talimatları

Ⓖ Assembly instruction

Ⓙ Istruzioni di montaggio







Ⓟ Instrukcja montażu

Ⓢ Navod na montaž

Ⓡ Instrucțiuni de montaj

Ⓡ Инструкция по монтажу

# 36-4530-82-000






# Service • Assistenza • Dienstverlening • Serwis Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam • Nazwa • Jméno • Názov  
Név • Denumire • Isim • Название



Nr. • No. • N° • Č • Sz • Номер

Typ • Type • Tip • Tipus • Druh • Тиро • Тип




## Detail specification

A.i. Nr.	Article Nr.	pcs
①	208444-82	x1
②	208448-82	x2
③	208445-82	x2
④	208446-82	x1
⑤	208447-82	x1
⑥	208439-32	x4
⑦	208449-52	x1



a




b



c

1-000001=



d



e



f




g


## Fitting specification

A.i. Nr.	Article Nr.	Dimensions	pcs
a	1-000013-00	8x40	x20
b	1-000121-07	34+11	x18
c	1-000048-07	15x12	x18
d	1-000053-07	D5/5	x12
e	1-000112-57	4x17	x18
f	1-000015-07	15gr.	x1
g	1-000062-07	3x20	x16


1.




2.1.




2.2.



3.



4.



5.

